

www.stress.com

Power Plant Fitness-For-Service

Waterwalls

Boiler waterwalls have always been among the most difficult challenges for design and life assessment, mainly because the failure modes appear to be outside the scope of design calculations. These notes identify some problem areas where progress has been made.


Waterwall Risk Management

Waterwall failures in supercritical boilers are generally regarded as the source of most forced outages. Failure modes are complex and involve combinations of severe environmental and



thermal-mechanical conditions. Aggressive external corrosion after conversion to low NOx burner systems has been the main cause of waterwall tube failures and replacements in supercritical units. The response to this by utilities has been the use of coatings and Ni-based weld overlays to prevent wastage in the reducing combustion environment. While weld overlays have been generally successful in controlling wastage, other failure modes have occurred, such as:

 Fatigue at terminations of weld overlay and other poor field-welded details



- Overheating failures due to factors such as fouling which requires more attention on supercritical than on subcritical units.
- Oxide cracking due to thermal-mechanical cycles
- Environmentally assisted creep-fatigue

Circumferential Cracking

Environmentally assisted creep-fatigue due to severe thermal cycles has been identified as the cause of circumferential cracking, usually initiating at multiple sites on the crown of the tube. Both plain and overlaid tubes have suffered from such cracking. In addition to the environmental factors mentioned above, contributing factors are:

- Frequent thermal cycling due to soot-blowing and slag falls
- High local heat fluxes
- Internal fouling leading to elevated tube metal temperatures.

Analysis of creep-fatigue damage using API/ASME data quantifies the thermal-mechanical contribution to circumferential cracking, and gives a basis for recommending limits to maximum heat flux and heat flux ranges.




temperature contours

Waterwall Failure Analysis & Troubleshooting

In addition to a metallurgical failure analysis, numerical models of failure increase the ability to manage and prevent failures. In most cases this will involve both environmental and thermal-mechanical effects. Managing the problem will require connecting the failure analysis to operational factors where possible. SES can provide:

- Tube failure analysis
- Creep-fatigue assessments based on heat flux cycles, for plain and weld overlaid waterwall tubes
- Recommendations for tube material upgrades

Local heat flux (BTU/ft/ft/hr) cycles for T11 supercritical waterwall tube 10 year design life



The complexity of tubewall failure analysis and life prediction requires a truly multidisciplinary approach. SES has well-recognized capabilities in areas where metallurgical and thermal-mechanical failure modes interact,

driven by combustion and fluid mechanics processes. The results are client-driven solutions beyond the scope of single-discipline approaches.



Tube thermal stress contours



Tube temperature contours

For More Information About Waterwall Risk Management Call SES Today

Houston 281-955-2900

Cincinnati 513-336-6701

New Orleans 504-889-8440

Baton Rouge 225-769-9772

ON THE WEB AT WWW.STRESS.COM